



### IMPORTANT INFORMATION AND RESTRICTIONS:

1. **When using several DZ209/5 or DZ209/10 diode boards, you must connect the terminals marked '8' on all the DZ209 diode boards together.**

### INSTALLATION GUIDELINES and GENERAL INFORMATION:

1. To install the DZ209 diode boards, simply remove the paper from the self-stick tabs and install into the back box in a convenient, dry location. Make sure none of the electrical contacts are being shorted.
2. The wiring shown can only be used with the 5461/5468 series Nocoax video-intercom system.
3. Make sure you connect the side of the DZ209 board labelled 'HT' to the selective terminals marked '1' on the model 5461 video monitor units.
4. See the 5461/5468 wiring diagram for the balance of the wiring connections required.
5. All wiring is #22 AWG, unless otherwise noted.
6. Observe all local and national electrical codes.
7. All terminals and connections shown may not be in the same order as they appear on the equipment.

 <p>42 Central Drive, Farmingdale NY 11735-1202          (631) 777-5500 Fax: (631) 777-5599  <b>TOLL-FREE Technical Line 1-800-666-4800</b>          Email: info@alphacommunications.com</p>	<p><b>DZ209 DIODE BOARD WITH 5468          INSTALLATION INSTRUCTIONS</b></p> <p>For use with the 5461 (Nocoax) Apartment          Video Monitor and Handset Station</p>
---	---