


**INSTALLATION GUIDELINES and GENERAL INFORMATION:**

1. All low voltage wiring is #22 AWG, unless otherwise noted.
2. Check for shorts and/or grounds before connecting transformer to IA543 / PK543A amplifier.
3. Install transformer at least 3 feet (1 meter) away from IA543 / PK543A amplifier.
4. Observe all local and national electrical and building codes.
5. All terminals connections shown may not be in the order that they appear on the equipment.
6. FOR BEST PERFORMANCE do not connect more than 3 inside stations in parallel.

 <p>42 Central Drive, Farmingdale NY 11735-1202 (631) 777-5500 Fax: (631) 777-5599 <b>TOLL-FREE Technical Line 1-800-666-4800</b> Email: info@alphacommunications.com</p>	<p><b>TYPICAL WIRING INSTRUCTIONS</b> <b>For the IA543 / PK543A Amplifier</b></p> <p>1-Entrance and up to Three (3) or Four (4) 4-Wire Inside Intercom Stations connected in parallel.</p>
--	--