



INSTALLATION GUIDELINES and GENERAL INFORMATION:

1. See the complete PK205 system wiring diagram (IL418) for the balance of the wiring connections required.
2. All low voltage wiring is #18 AWG, unless otherwise noted.
3. All terminals shown may not be in the exact same order as they appear on the equipment.
4. Observe all local and national electrical and building codes.



42 Central Drive, Farmingdale NY 11735-1202
 (631) 777-5500 Fax: (631) 777-5599
 TOLL-FREE Technical Line 1-800-666-4800
 Email: info@alpha-comm.com

**TYPICAL INTERNAL SCHEMATIC
 WIRING FOR THE TA305 MASTER
 HANDSET WHEN USED WITH THE
 PK205 SYSTEM AMPLIFIER**