



### INSTALLATION GUIDELINES and GENERAL INFORMATION:

1. All low voltage wiring is #22 AWG, unless otherwise noted.
2. Observe all local and national electrical and building codes.
3. All terminals connections shown may not be in the order that they appear on the equipment.
4. When using the TA201B (buzzer) style handset in place of the TA205B (tone) style handset, make sure the lobby panel pushbutton common wire goes to PK205 terminal 'T' and not 'Z'.



42 Central Drive, Farmingdale NY 11735-1202  
(631) 777-5500 Fax: (631) 777-5599  
TOLL-FREE Technical Line 1-800-666-4800  
Email: info@alphacommunications.com

### TYPICAL WIRING INSTRUCTIONS For using the PK205 Amplifier/Power Supply in place of the PK201 Amplifier with TA201B (5-wire) Remote Handsets