

INSTALLATION GUIDELINES and GENERAL INFORMATION:



- 1. All low voltage wiring is #22 AWG, unless otherwise noted.
- 2. Observe all local and national electrical and building codes.
- 3. All terminals connections shown may not be in the order that they appear on the equipment.
- 4. This diagram does not show all of the possible configurations possible for the CM800 system. This is a simplified diagram showing in more detail the most popular system configuration and components. For the complete system installation manual and additional wiring diagrams, please see installation manual #IL514.
- 5. Optional wiring and components are shown in dotted lines.



TYPICAL WIRING INSTRUCTIONS For the CM800 Emergency-Call System (simplified diagram) showing the most popular system components