



INSTALLATION GUIDELINES and GENERAL INFORMATION:

1. All low voltage wiring can be #22 AWG to #18AWG unless otherwise noted.
2. Observe all local and national electrical and building codes.
3. All terminals connections shown may not be in the order that they appear on the equipment.
4. Please refer to the actual SimpleBUS2 installation and use manual for complete wiring details.
5. You can inter-mix the 5701, 5702, 5801, 5802, 6101 and 2638 apt. stations in one system.



42 Central Drive, Farmingdale NY 11735-1202
(631) 777-5500 Fax: (631) 777-5599
TOLL-FREE Technical Line 1-800-666-4800
Email: info@alphacommunications.com

TYPICAL BLOCK WIRING DIAGRAM
For using the 2-Wire SimpleBUS2 series
video-intercom and/or intercom system
with a single digital-dial entry station.