



**INSTALLATION GUIDELINES and GENERAL INFORMATION:**

1. On each 870 and/or 8870 handset you need to put a jumper wire between terminals '2' and '4/5'.
2. On each 870 and/or 8870 handset you need to put a diode (model #027 or equivalent) between terminals '1' and '6' with the striped side of the diode going to terminal '1' (polarity must be observed).
3. This wiring diagram must be used in addition to the separate 142 or 142A series installation manual(s).
4. All wiring is #22 AWG, unless otherwise noted.
5. Observe all local and national electrical and building codes.
6. All terminals and connections shown may not be in the same order as they appear on the equipment.

<p>42 Central Drive, Farmingdale NY 11735-1202 (631) 777-5500 Fax: (631) 777-5599 <b>TOLL-FREE Technical Line 1-800-666-4800</b> Email: info@alphacommunications.com</p>	<p><b>870 and/or 8870 Series Handsets INSTALLATION INSTRUCTIONS</b></p> <p>For use with the 142 or 142A Series Switchboard Master Station - showing 2-Wire Modifications</p>
--	--