

This diagram represents a typical basic system. For more specific details and variations, please refer to the NC110A - NC110N Installation & Operation Manual IL381.



TYPICAL BLOCK WIRING DIAGRAM FOR SINGLE MASTER NC110 SERIES NURSE-CALL SYSTEM - without 3rd priority level for Code Calls or Smoke Detectors etc.