



TITLE: AF-3600 WIRING DIAGRAM
 DWG NO. -254180
 USED ON: MULTIPLE ENTR. SYSTEMS
 DRN: TM | CHK:KN | DATE:05/27/2002



- NOTES:
1. All wiring should be tin/copper 22 AWG unless noted otherwise.
 2. DO NOT run vestibule spkr. Wire in the same cable as the apt. Signal & Common wires.
 3. Run all intercom wires separately from AC wires.
 4. For DC door release operation, connect door release to I+ and I-.
 5. For 16 VAC door release, use transformer model ITR1.



42 Central Drive, Farmingdale NY 11735-1202
 (631) 777-5500 Fax: (631) 777-5599
TOLL-FREE Technical Line 1-800-666-4800
 Email: info@alphacommunications.com

TYPICAL WIRING INSTRUCTIONS
 For the AF-3600 Dual Entrance Adapter
 for use with the AF-1000 apt. intercom
 amplifier unit.