



Resident Instructions for the VFS1000 Series Video Monitor Station


DOOR RELEASE Button

Press to allow visitors to enter

RING VOLUME Button

With the Station OFF, hold down this button to adjust the ring volume. As you continue to hold it, you will hear the ring tone slowly go from loud to soft and then back to loud again. When you get to the volume you prefer, release the button and the level will stay there.

If the volume is all the way down, the red light behind this button will flash to warn that the unit will not ring when called. The green light behind the ON/OFF button will still flash when the station is called.



ON/OFF Button

This button will flash Green when this station is called.

To accept the call, press this button.

At the end of the conversation, you may push this button to shut off the monitor.

RING STYLE Button

With the Station OFF, hold down this button to change the ring style.

While holding it down, press and release the ring volume button on the left to hear the various rings.

Repeat until you have heard the one you wish to select, then release both buttons.

Please Note: Other features and functions may be available depending on system configuration