


INSTALLATION GUIDELINES and GENERAL INFORMATION:

1. All low voltage wiring is #22 AWG, unless otherwise noted.
2. See wiring diagram/installation manual #AWD011 for balance of system wiring information.
3. Observe all local and national electrical and building codes.
4. All terminals connections shown may not be in the order that they appear on the equipment.

 <p>42 Central Drive, Farmingdale NY 11735-1202 (631) 777-5500 Fax: (631) 777-5599 TOLL-FREE Technical Line 1-800-666-4800 Email: info@alphacommunications.com</p>	<p>TYPICAL WIRING DIAGRAM FOR TU1007A Multi-Entrance Adaptor used With NH201TT or NH201TVA Amplifier/Power Supply for a two (2) entrance building application.</p>
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------