



NOTES: All wiring #18AWG unless shown otherwise.

All connections shown with dotted lines are optional wiring configurations.

Do not connect the SS106 transformer to the AC219 or SK019 unit(s).

Use the 24VAC connections on the SS106 transformer.

Terminal connections shown may not be in the actual order they appear on the equipment.

For balance of system wiring, please see the specific AlphaEcallTM, CM800 or DS100 installation manual.



Typical Wiring Diagram for the AC219 control unit with the PK124 battery charger, for AlphaEcall™, CM800 and/or DS100 systems.