


NOTES:

1. This wiring diagram is to be used **IN ADDITION TO** the standard DS100 wiring diagram(s). The White wires coming off of the SF119/2A pull cords will get connected to the standard DS100 system wiring, and the Black wires coming off of the SF119/2A pull cords will get connected to the separate Dome Light portion of the system and separate 24VAC or 24VDC Power Supply.
2. When using a 24VAC Dome light you need a 24VAC Power Supply, and when using a 24VDC Dome light you need a 24VDC Power Supply.
3. Terminal connections shown may not be in the actual order they appear on the equipment.

 <p>42 Central Drive, Farmingdale NY 11735-1202 (631) 777-5500 Fax: (631) 777-5599 TOLL-FREE Technical Line 1-800-666-4800 Email: info@alphacommunications.com</p>	<p>Typical Wiring Diagram using SF119/2A Pull Cords (instead of the SF117/2A) with a DS100 system that requires individual apartment Dome Lights</p>
--	---