



TB10-17

1 2 3 4 5 6



-	
+ 24V DC	TWISTED PAIR

A

B

TWISTED PAIR

A TWISTED PAIR

P3

- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8

PCB971

J1

NOTE: terminals shown may not be in the order that they appear on the equipment.

AA918
Master
Station



42 Central Drive, Farmingdale NY 11735-1202
(631) 777-5500 Fax: (631) 777-5599
TOLL-FREE Technical Line 1-800-666-4800
Email: info@alphacommunications.com

Wiring diagram for the AA918 Series Master Station when connecting to the GF934J Wall Bracket with Jack