



NOTE:
When using the ST-FOOT-P foot switch for Push-To-Talk, connect to terminals '1' & '2' on the P2 terminal strip.

Alternately, you can use the foot switch for Push-To-Cancel by connecting to terminals '1' & '4' instead.

PC Board on Rear of SS200 series Master Station

NOTE: terminals shown may not be in the order that they appear on the equipment.



42 Central Drive, Farmingdale NY 11735-1202
(631) 777-5500 Fax: (631) 777-5599
TOLL-FREE Technical Line 1-800-666-4800
Email: info@alphacommunications.com

Wiring diagram for the SS201 Clean Room Intercom system and showing the optional ST-FOOT-P Press-To-Talk Foot Switch and SF001J Wall Jack