


**Connect to the (2)
outer screws on
the SS106 24VAC
transformer**

NOTES:

- 1. Polarity must be observed on the 'N' and 'P' terminals.**
- 2. All (3) 'P' terminals on the PK624 are the same. You can connect to any of the (3) 'P' terminals.**

INSTALLATION GUIDELINES and GENERAL INFORMATION:

1. See the specific system wiring diagram for the balance of the wiring connections required.
2. All low voltage wiring is #18 AWG, unless otherwise noted.
3. All terminals shown may not be in the exact same order as they appear on the equipment.
4. Observe all local and national electrical and building codes.

 <p>42 Central Drive, Farmingdale NY 11735-1202 (631) 777-5500 Fax: (631) 777-5599 TOLL-FREE Technical Line 1-800-666-4800 Email: info@alpha-comm.com</p>	<p>TYPICAL WIRING INSTRUCTIONS FOR PK624 Conversion Power Supply To convert a 24VAC input into a 15VDC output</p>
-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------